

ACADEMY / STUDY BOOK

Battery & Starting-System Testing

Interpret battery test conditions, distinguish no-crank from slow crank, and build a measured starting-system test plan.



Scan to continue this course online and find more Academy training.
<https://mechanicroster.com/index.php/academy/battery-starting-system-testing>

How to use this book

Read the lessons, work each example, then complete the practice questions before checking the answer explanations. Write your evidence and next step in the exercises. Training examples are not vehicle service specifications.

Mechanic Roster Academy is independent.

Edition 2026.10.15 | Free to download and print with branding retained.

Before you begin

Electrical Measurement Foundations is recommended. Low-voltage knowledge only; no high-voltage battery service.

Learning objectives

- Identify the actual starting complaint and battery type.
- Distinguish state of charge from demonstrated performance.
- Interpret loaded cable-loss and starting observations using supplied limits.
- Verify the correction and document remaining uncertainty.

Course contents

Identify the complaint and safe test conditions

Understand battery test meaning and limitations

Evaluate the starting circuit under load

Verify the repair and explain the outcome

Worked shop cases / Practical worksheet / Practice assessment / Answer explanations / Further study

Identify the complaint and safe test conditions

Separate no-crank, slow-crank and normal-crank/no-start complaints. A normal-speed cranking engine that does not run is not automatically a starter failure. Ask whether the problem occurs cold, hot, after parking, intermittently or after recent service. Record warning messages and the vehicle's observed behavior rather than relying on "dead battery" as a complete diagnosis.

Identify the installed low-voltage battery type, rating and location, along with the approved test and connection points. Some vehicles use battery monitoring, remote terminals, start-stop systems or battery registration procedures. Follow the actual application rather than assuming every vehicle uses the same charging or replacement process.

Inspect for case damage, leakage, loose mounting, damaged cables and inappropriate connections before testing. Use required protective equipment and safe work-zone practices. Do not charge or jump a battery whose condition makes that unsafe under the manufacturer's guidance. Keep sparks and inappropriate connections away from the system. This course does not provide a universal jump-start sequence.

Define the fault

The driver says "battery dead," but the engine cranks at normal speed and does not start. Record that distinction and select the appropriate diagnostic path. Selling a battery based solely on the phrase would skip the actual evidence.

Set the test scope and preserve relevant fault data. Unusual hybrid/EV conditions require the proper safety boundary; a familiar low-voltage battery does not authorize traction-system work.

Separate charge from ability to perform

A battery's state of charge describes available charge at that time; condition describes its ability to meet the applicable performance requirement. A discharged battery may need the specified charge-and-retest process before a valid condition decision. A satisfactory resting voltage alone does not prove that it can supply starting current. Conversely, a failed starting event does not prove the battery caused it.

Identify the installed chemistry/type, rating value and rating standard. The same number entered under the wrong standard may produce a misleading tester conclusion. Inspect accessible condition and connections using the required precautions. Damage, leakage, abnormal heat or another hazard changes the plan; a routine tester connection is not the next step for every battery presented to the bay.

Record the setup

Write the vehicle identity, battery identification, temperature context, test mode, connection points and result exactly enough to reproduce the decision. If the tool says charge and retest, preserve that instruction and the subsequent result rather than relabeling it "bad." A printed slip with no matching battery data is weak evidence for either replacement or continued service.

Classify the starting complaint first

Distinguish no crank, slow crank and crank-but-no-start before choosing tests. A starter-circuit test plan does not by itself diagnose a running engine that will not fire. Ask about temperature, time parked, recent work, warning messages and whether the problem is repeatable. Preserve relevant diagnostic information before clearing or disconnecting anything.

Inspect the battery's physical condition and identify its type and application before using test or charging equipment. A damaged or leaking case changes the safety plan. Do not use an acceptable voltage reading to dismiss a physical hazard. Record the difference between a customer report and a reproduced condition; "would not start yesterday" is not the same as today's measured slow-crank event.

Separate starting concerns

- No crank Check the applicable command and power path
- Slow crank Evaluate battery, path losses and mechanical load
- Cranks normally Use the appropriate no-start diagnostic path
- Intermittent Document the conditions needed to reproduce

Try it before reading the answer

The engine rotates normally but does not run. Is replacing the starter supported by that observation?

Worked answer and reasoning

No. Normal rotation does not prove the cause of the no-start, but it does not support a starter replacement by itself. Route the concern into the applicable crank-but-no-start diagnostic process and preserve relevant evidence.

Understand battery test meaning and limitations

State of charge and battery performance are different questions. A resting voltage observation may help evaluate charge state under defined conditions, but does not alone prove the battery can deliver required current. Temperature, recent charging, surface charge, battery chemistry and rest conditions affect interpretation. Use the tester and vehicle procedures rather than a universal pass voltage.

Enter the correct battery type and rating standard into an approved tester. A rating expressed under one standard should not be entered as though it were another. Poor clamp contact or wrong input data can invalidate a printed result. Record the selected settings, relevant conditions and the test instruction or result.

If the tester calls for charging and retesting, follow that direction when safe. "Charge and retest" is not the same result as "replace." A discharged battery can be the consequence of another issue, including use pattern, connection condition, charging behavior or unwanted draw; replacement alone may not resolve the underlying problem.

Interpret the report

Two reports disagree. One used the wrong battery type and rating; the second used verified inputs and correct connection. Do not average them. Correct the method and repeat as required. A professional-looking printout does not validate incorrect setup.

Keep the actual test report with the repair order and explain its meaning without turning a limited result into a guarantee of future starting.


Describe the starting symptom precisely

No crank means the engine is not being rotated by the starting system. Slow crank means rotation occurs but is slower than expected under the relevant conditions. Crank-no-start means the engine rotates but does not run. These descriptions lead to different investigations. A customer saying "won't start" does not yet identify which one occurred.

Ask whether the condition is cold, hot, intermittent or associated with recent work. Note the sounds and indicator behavior without treating them as unique diagnoses. A click may indicate that part of a control path responded, but it does not prove every main-current connection or mechanical component is sound. For no-crank, the required command, interlock and control conditions must be evaluated through the applicable procedure.

Compare the symptom with the authorized scope. Battery testing is one check, not a complete diagnosis of every starting complaint. If a fault is not currently present, document the test conditions and uncertainty. Do not report that a hot intermittent problem was resolved solely because the engine cranked once while cold.

TEST THE CIRCUIT UNDER LOAD



Conceptual voltage budget - not a wiring diagram.

$$\text{Supply voltage} = \text{load voltage} + \text{feed loss} + \text{return loss}$$

Measure under the specified load. Compare with vehicle-specific limits.

MECHANIC ROSTER


Measure circuit losses under load and compare with the vehicle procedure.

Interpret a battery result within its conditions

State of charge, test method, temperature, battery specification and equipment setup affect what a result means. “Good voltage” is incomplete without the points, operating state and reference. A discharged battery may be the consequence of another problem rather than the original cause. Distinguish the need to restore a valid test condition from a decision to replace the battery.

Suppose a fictional tester requests charging and retesting. That is not the same result as a confirmed failed battery. Follow the tester and vehicle instructions and investigate why the battery was discharged when the evidence warrants it. Repeated replacement without checking the underlying condition may leave the customer's concern unresolved. Record the final valid result rather than keeping only a convenient initial reading.

TEST THE CIRCUIT UNDER LOAD



Conceptual voltage budget - not a wiring diagram.

$$\text{Supply voltage} = \text{load voltage} + \text{feed loss} + \text{return loss}$$

Measure under the specified load. Compare with vehicle-specific limits.

MECHANIC ROSTER

Battery voltage and starting-path losses are separate. This low-voltage concept drawing is not a vehicle wiring diagram. Measure under the prescribed starting conditions with suitable equipment and the actual vehicle procedure. Concept illustration; use the vehicle-specific procedure for service.

Try it before reading the answer

A low-charge result follows repeated unsuccessful starting attempts. Which conclusion is premature?

Worked answer and reasoning

It is premature to call the battery the original cause solely from its low charge after repeated attempts. Establish the required test condition, retest as directed, and evaluate the starting complaint and cause of discharge separately.

Evaluate the starting circuit under load

The starter needs an appropriate supply, return path, control and mechanical conditions. A click is an observation, not a complete diagnosis. Follow the starting-system procedure to distinguish battery performance, cable loss, control issues, starter operation and mechanical resistance. Do not bypass interlocks or energize circuits through improvised methods.

Loaded voltage-drop tests can identify loss in the feed or return path. The meter measures across the segment while the relevant current flows. An unloaded voltage reading may miss a resistive connection. Use specified test points and limits; do not condemn a starter before evaluating the conditions it receives.

Fictional cranking exercise - not universal limits

Segment	Measured loss	Exercise maximum
Positive path	0.70 V	0.30 V
Return path	0.12 V	0.20 V

The positive path fails the stated criterion, while the return passes this test. Subdivide the positive path under comparable load to locate loss. This does not prove the whole cable must be replaced; the problem may be at a connection that still needs inspection.

If a vehicle starts after charging but repeatedly becomes discharged, develop a separate approved charging or parked-current investigation. Sleep states and connected modules make parked-current testing vehicle-specific. Do not assume every immediate current reading represents a settled vehicle.

Interpret measurements under the same event

Starting places a substantial load on the low-voltage circuit. Source voltage, supply loss, return loss and current must be interpreted with the event and applicable specifications. Measurements from different temperatures or different cranking conditions may not be directly comparable. Record the conditions, not just the smallest number captured by a meter.

In a fictional event the source measures 10.6 V, the positive path loses 0.9 V and the return path loses 0.2 V. The difference across the load is about 9.5 V in this simplified model. If the supplied positive-path maximum is 0.4 V, that path needs investigation. The result does not itself identify a starter fault or establish a universal acceptable cranking voltage.

Localize before replacing

Divide an excessive path loss into meaningful sections while maintaining the required test conditions. A cable can appear intact externally while a connection or conductor is defective. A low unloaded resistance reading may miss loss under starting load. Correct the supported defect, then repeat the relevant event. Follow duty-cycle and safety instructions; repeatedly cranking simply to gather more numbers can introduce additional problems.

Compare both sides of the starting circuit

Use simultaneous or properly comparable readings when applying a simplified voltage budget. In the fictional exercise, supply during the test is 10.8 V, feed loss is 0.6 V and return loss is 0.3 V. The load receives approximately 9.9 V under that condition. These values are not universal limits. A path loss requires comparison with the applicable method and reference.

A feed-side pass does not cancel a return-side failure. Localize the failing path by testing appropriate segments under comparable load. A small unloaded resistance or continuity result may not reveal a connection that loses voltage during cranking. Avoid prolonged or repeated cranking outside the vehicle/equipment instructions; the diagnostic plan must respect duty-cycle and safety constraints.

Fictional starting voltage budget

Measured quantity	Training value
Supply under test	10.8 V
Feed loss	0.6 V
Return loss	0.3 V
Calculated load voltage	9.9 V

Try it before reading the answer

A second test records 11.0 V supply, 0.4 V feed loss and 0.2 V return loss. Calculate load voltage. Does this alone establish battery capacity?

Worked answer and reasoning

Load voltage is $11.0 - 0.4 - 0.2 = 10.4$ V. The budget does not establish battery capacity by itself. Interpret battery performance through the appropriate battery test and all readings under the relevant test conditions.

Verify the repair and explain the outcome

After the authorized correction, repeat the measurement and starting conditions that identified the problem when safe. A cable-loss improvement should be measured at the same points under comparable cranking conditions. One successful start does not fully resolve a complaint that only appears after an overnight park or hot soak.

If a battery is replaced, verify the correct type, rating, secure mounting, connection procedure and any specified registration or initialization. Follow applicable torque and connection instructions. Do not use a memory of another vehicle's battery-monitoring procedure as a universal substitute.

Document what was corrected, the test results, any required initialization and the observed starting outcome. Explain remaining diagnostic limitations. A customer may reasonably ask why a new battery did not solve a recurring discharge; the record should show whether the cause of discharge was investigated or only the battery's condition was addressed.

Evidence-based handoff

"The positive path exceeded the exercise loss limit under cranking. The authorized connection repair reduced loss under the same test, and the reported slow-crank condition was not observed during verification. An overnight discharge concern would require the separate agreed test." This describes the actual scope instead of promising that all starting problems are impossible.

Keep low-voltage and high-voltage conclusions separate. This certificate records knowledge of the named testing process, not practical authorization for every battery system.

Replacement is a controlled service, not the end of diagnosis

Verify type, rating, dimensions, terminals, retention and any vehicle-specific registration or reset procedure for a replacement. Similar appearance is not complete compatibility. Preserve required settings or data through the approved method; do not improvise power support around an unfamiliar electrical system. Inspect the related mounting and connection condition before returning the vehicle.

After the authorized work, repeat the relevant tests and the original starting condition when practical and safe. A successful cold start is limited evidence for a heat-related failure. If discharge was the concern, distinguish a failed battery from an unresolved cause of discharge. Charging-system or parasitic-load investigation may require separate authorization and procedures; a new battery does not automatically eliminate those possibilities.

Customer explanation

State whether the original battery was discharged, failed a valid condition test, or passed the performed checks. Explain what was corrected and what remains untested. Keep the tester report, entered rating, before/after loss measurements and relevant procedure completion together. The customer should be able to understand why the recommendation followed the evidence.

Prove the repair without making a blanket promise

Link the original complaint to a repeatable verification. If a repaired connection reduced a path loss and the original slow-crank condition no longer appears under comparable conditions, record both findings. If the vehicle was only checked warm but the complaint occurs after an overnight cold soak, preserve that limitation. A single successful start is not proof that every intermittent starting problem is eliminated.

Keep battery replacement, circuit repair and required initialization or registration steps distinct in the record. Use the applicable vehicle instructions to identify required follow-up. Explain the measured condition, corrective work and next action if a concern returns. Customers benefit from a clear record more than a broad guarantee unsupported by testing.

Starting-system completion

- Baseline Reproduced condition and valid measurements
- Correction Work tied to the identified fault
- Retest Comparable load and operating state
- Handoff Results, required setup and limitations

Try it before reading the answer

A warm retest passes after a repair, but the original issue occurred only on cold mornings. Write an accurate completion limitation.

Worked answer and reasoning

“The repair passed the documented warm verification; the original cold-start conditions have not yet been reproduced.” Include the plan for a suitable cold check or follow-up rather than claiming all conditions have been verified.

Work the shop cases

The tester says charge and retest

A customer reports an overnight no-start. The battery tester was set to the correct installed type and rating and returns “charge and retest.” An advisor wants to sell a replacement immediately because the car needed a jump. No damage or immediate hazard was found in the authorized inspection.

Explain what the result establishes and what it does not. Write the next service decision and the additional questions needed if the battery later passes but the overnight complaint returns.

Your evidence, decision and next step:

Compare with the model answer

The test has not yet established a final condition verdict under its required process. Follow the specified charging and retest method when safe and authorized, then retain both results. A jump-start is evidence about the event, not proof of one failed component. If the battery passes and the complaint returns, examine usage history, charging performance and possible unwanted draw through the relevant authorized diagnostic procedure. Do not promise that replacing the battery alone will fix an uninvestigated discharge cause.

High supply loss during slow cranking

During one fictional slow-crank event, source voltage is 10.6 V, positive-path loss is 0.9 V and return-path loss is 0.2 V. The supplied positive-path maximum is 0.4 V. A teammate proposes a starter because it rotates slowly. The prior cable check was performed with no operating load.

Calculate the approximate load voltage, identify the supported investigation area and write a before/after verification plan.

Your evidence, decision and next step:

Compare with the model answer

In the simplified example, $10.6 - 0.9 - 0.2 = 9.5$ V across the load. The positive path exceeds its supplied criterion and must be localized under comparable conditions. The unloaded check does not eliminate that loss. Inspect/test the relevant path sections through the prescribed safe method before assigning a component verdict. After correcting the supported defect, repeat the loaded measurements and evaluate cranking under the original conditions. A normal path result still requires the rest of the system decision; it is not a universal starter test.

Apply it to a job

Classify three complaints: no crank, slow crank, normal crank/no start. Create a battery tester setup checklist. Interpret the fictional cable-loss table and choose a localization test. Write a charge-and-retest result without prematurely recommending replacement. Draft a verification plan for a hot-only starting concern.

Concern / scenario

Observation, measurement and reference

Interpretation and next action

Unknowns and who needs to review

Verification and handoff

Check your understanding

- Distinguish state of charge from condition.
- Separate no-crank, slow-crank and crank-no-start complaints.
- Interpret a tester instruction without changing its meaning.
- Use same-event measurements to localize a loss.
- Explain why replacing a battery may not resolve discharge.

Practice assessment

Ungraded practice, separate from the final assessment. Answers and reasoning follow in the next section.

1. The engine cranks normally but does not run. What is the complaint category?

- A. Normal-crank/no-start
- B. No-crank
- C. Slow-crank
- D. Confirmed battery failure

2. A tester says charge and retest. What does that mean?

- A. Replace immediately in every case.
- B. Follow the safe prescribed charge/retest process before a final conclusion.
- C. Record a full pass.
- D. Average it with a previous result.

3. Positive-path loss is 0.7 V against a supplied 0.3 V maximum. What is supported?

- A. The starter is uniquely proven failed.
- B. All cables pass.
- C. The tested path fails and needs localization.
- D. The battery capacity is known.

4. A hot-only concern is checked once cold. Is verification sufficient?

- A. Yes because it started.
- B. Yes because the invoice is complete.
- C. Only the battery brand decides.
- D. No; the relevant hot condition remains untested.

5. 11.0 V minus 0.4 V feed and 0.2 V return losses leaves what?

- A. 10.4 V
- B. 10.8 V
- C. 11.6 V
- D. 0.6 V

6. What is a useful intake distinction?

- A. Battery brand versus invoice color
- B. No crank versus slow crank versus crank-but-no-start
- C. Starter price versus service date only
- D. Customer diagnosis versus parts availability only

7. A leaking battery case has an acceptable open-circuit voltage. What controls the next action?

- A. The voltage alone
- B. The customer's requested completion time
- C. The physical safety concern and applicable procedure
- D. The age shown on the invoice alone

8. A reduced path loss after repair proves what?

- A. Every circuit is satisfactory
- B. Battery capacity is certified
- C. All cold faults are eliminated
- D. Improvement at the tested path and conditions

Answer explanations

1. Normal-crank/no-start

Observed cranking behavior separates the category; it does not by itself identify a failed part.

Review: Identify the complaint and safe test conditions

2. Follow the safe prescribed charge/retest process before a final conclusion.

The instruction is an intermediate decision, not a pass or automatic replacement verdict.

Review: Understand battery test meaning and limitations

3. The tested path fails and needs localization.

The comparison concerns that loaded segment, not all possible starting causes.

Review: Evaluate the starting circuit under load

4. No; the relevant hot condition remains untested.

Verification should address the original relevant conditions.

Review: Verify the repair and explain the outcome

5. 10.4 V

The load voltage is the source less both losses.

Review: Evaluate the starting circuit under load

6. No crank versus slow crank versus crank-but-no-start

The operating symptom directs the diagnostic path.

Review: Identify the complaint and safe test conditions

7. The physical safety concern and applicable procedure

An electrical reading does not negate a physical hazard.

Review: Understand battery test meaning and limitations

8. Improvement at the tested path and conditions

Keep the conclusion within the evidence.

Review: Verify the repair and explain the outcome

Further study

Use current vehicle and equipment information for actual service. These resources support further learning; lessons and questions in this book are original.

Fluke automotive multimeter tests

<https://www.fluke.com/en/learn/blog/digital-multimeters/common-automotive-testing-with-a-multimeter>

ASE automobile electrical task outline

https://www.ase.com/wp-content/uploads/ASE_Automobile_Study_Guide.pdf

Voltage-drop diagnostic principles - Fluke

<https://www.fluke.com/en-us/learn/blog/automotive/electrical-automotive-troubleshooting>